

Index

A

About this manual - 5
Accelerator pedal - 70
Acknowledgements - 2
Aerial - 136, 139, 211
Air cleaner - 64, 200
Alternator - 126, 210, 211
Ancillary components (engine) - 39, 50
Antifreeze - 55
Axle (rear) - 158, 216

B

Balljoint (tie-rod) - 148
Battery - 125, 210
Bearings
 clutch release - 84
 crankshaft - 42, 46
 wheel hub - 110
Bleeding (brakes) - 120
Block (engine) - 42
Bodywork and fittings - 18, 161 *et seq*, 182, 216 *et seq*
Bonnet - 162, 163
Brake pads - 112
Brake shoe linings - 114
Braking system - 18, 112 *et seq*, 182, 210
Bulb renewal - 129
Bumpers - 162, 217
Buying spare parts - 9

C

Cables
 bonnet release - 163
 choke control - 71
 clutch - 82, 208
 handbrake - 122
 speedometer - 134
Caliper - 116, 210
Cam followers - 43, 48, 194
Camshaft - 43, 186, 194
Capacities - 6
Carburettor - 67 to 69, 201, 202
Cassette player - 142
CB radio - 144
Centre console - 172
Choke - 71
Clock - 134, 211
Clutch - 82 *et seq*, 182, 208 *et seq*
Coil (ignition) - 80, 207
Column (steering) - 129, 148, 150
Condenser - 78
Connecting rods - 33, 42, 49, 190, 191
Console - 172

Constant velocity joint (driveshaft) - 109
Contact breaker points - 76
Conversion factors - 13
Coolant - 55
Coolant pump - 58, 199
Cooling and heating systems - 18, 54 *et seq*, 182, 198 *et seq*
Courtesy lamp - 129, 131, 134
Crankcase - 42
Crankcase ventilation system - 29
Crankshaft - 42, 46
Cylinder block - 42
Cylinder head - 29, 40, 44, 49, 186, 194

D

Damper (steering rack) - 150
Decarbonising (engine) - 40
Differential - 96
Dimensions - 6
Direction indicators - 130
Disc brakes - 112, 116, 117
Distributor - 79, 205, 207
Doors - 164, 165
Draining cooling system - 55
Drivebelt - 57, 211
Driveshafts - 18, 106 *et seq*, 182, 208 *et seq*
Drum brakes - 114, 117
Dwell angle - 78

E

Electrical system - 18, 124 *et seq*, 182, 210 *et seq*, 217
Engine - 18, 24 *et seq*, 182, 183 *et seq*
Exhaust - 71
Exterior lamps - 129, 131, 132, 211

F

Facia panel - 169
Fanbelt - 57
Fan (cooling system) - 57, 200
Fault diagnosis
 braking system - 123
 clutch - 85
 cooling system - 62
 driveshafts, hubs, wheels and tyres - 111
 electrical system - 145
 engine - 52
 fuel system - 72
 general - 20
 ignition system - 81
 steering - 154
 suspension - 159
 transmission - 105

Filling cooling system - 55
 Flushing cooling system - 55
 Flywheel - 43, 47
 Front suspension - 155, 156
 Fuel filter - 203
 Fuel pump - 65, 66, 201
Fuel system - 18, 63 *et seq*, 182, 200 *et seq*
 Fuel tank - 66, 201, 203
 Fuses - 128, 211

G

Gaiter
 driveshafts - 208, 210
 steering rack - 148
 Gaskets (general) - 46
 Gearbox *see* Transmission
 Gearchange lever - 87
 Geartrains - 95
 Grille (radiator) - 163, 217

H

Handbrake - 121, 122
 Headlamps - 129, 131, 132, 211
 Heated rear window - 136
 Heater - 60
 Horn - 129
 HT leads - 80, 207
Hubs - 18, 106 *et seq*, 156, 182, 208 *et seq*

I

Idle speed adjustment - 68
 Ignition coil - 80, 207
Ignition system - 18, 74 *et seq*, 150, 182, 205 *et seq*
 Ignition timing - 78
 Indicators - 130
 Instrument panel - 131, 132, 213
 Intake manifold - 71
 Interference suppression (radio) - 140 to 142, 144
 Interior lamp - 129, 131, 134
 Introduction to the Fiat Panda - 5

J

Jacking - 7

L

Lamps - 129, 131, 132, 211
 Leaf spring - 158
 Linings (brake shoes) - 114
 Load levelling device (headlamps) - 211
 Locks
 bonnet - 162
 steering column - 150
 Loudspeakers - 139
 Lower track control arm - 156
 Lubricants and fluids - 19

M

Main bearings - 46
 Mainshaft - 95
 Maintenance *see* Routine maintenance
 Manifolds - 71
 Master cylinder - 118
 Mirror - 134, 171, 217
 Mixture adjustment - 68
 Mountings (engine) - 36, 191

N

Number plate lamp - 131, 211

O

Oil filter - 29
 Oil pump - 36, 45, 48, 188, 194
 Oil seals (general) - 46

P

Pads (braking system) - 112
 Parcels shelf - 169
 Parking lamp - 130
 Pedals
 accelerator - 70
 brake - 122
 clutch - 84, 208
 Pistons and rings - 33, 42, 49, 190, 191
 Points (contact breaker) - 76
 Pressure regulating valve (braking system) - 119, 210

R

Rack (steering) - 148, 150
 Radiator - 56
 Radiator grille - 163, 217
 Radio - 136, 139, 211
 Radius rod - 156, 214
 Rear axle - 158
 Rear lamp cluster - 130
 Rear suspension - 158, 214, 216
 Rear view mirrors - 171
 Regulating valve (braking system) - 119
 Relays - 128, 211
 Release cable (bonnet) - 163
 Release mechanism (clutch) - 84
 Repair procedures - 10
 Roadwheels - 111
 Rockers and rocker shaft - 44
 Rocker switches - 129
 Roof rack - 171
 Routine maintenance
 bodywork - 18, 160, 182
 braking system - 18, 112, 182
 clutch - 18, 82, 182
 cooling and heating systems - 18, 54, 182
 driveshafts, hubs, wheels and tyres - 18, 107, 182
 electrical system - 18, 125, 182
 engine - 18, 29, 182
 fuel system - 18, 64, 182
 ignition system - 18, 182
 steering - 18, 147, 182
 suspension - 18, 155, 182
 transmission - 18, 86, 182

S

- Safety first!
 - electrical system - 126
 - general - 14
- Seat belts - 170, 217
- Seats - 169
- Secondary shaft - 95
- Shock absorber - 158, 214
- Shoes (braking system) - 114
- Side trim panel - 165
- Side window - 169
- Spare parts - 9
- Spark plugs - 80, 207
- Speakers - 139
- Speedometer - 134
- Spring (rear suspension) - 158, 214
- Sprockets (timing chain) - 35, 48
- Starter motor - 126, 128, 211
- Steering - 18, 129, 146 *et seq*
- Steering column - 129, 148, 150
- Steering wheel - 148
- Strut (front suspension) - 155
- Sump pan - 32, 49, 183, 188
- Sun roof - 172
- Supplement: Revisions/information on later models - 173 *et seq*
- Suppression (radio interference) - 139
- Suspension - 18, 155 *et seq*, 182, 214 *et seq*
- Switches
 - coolant temperature - 58
 - courtesy lamp - 129
 - electric cooling fan - 57
 - horn - 129
 - ignition - 129, 150, 213
 - lighting - 213
 - rocker - 129
 - steering column - 129, 150

T

- Tailgate - 135, 136, 165, 168
- Temperature switch (coolant) - 58
- Thermostat - 56, 199

- Throttle pedal - 70
- Tie-rod end balljoint - 148
- Timing belt - 185, 194
- Timing chain - 35, 43, 48
- Timing (ignition) - 78
- Tools - 11
- Towing - 7
- Track control arm - 156
- Transmission - 18, 38, 39, 50, 51, 86 *et seq*, 182, 191, 208
- Trim panels - 163, 165
- Tripod joint (driveshaft) - 108
- Tyres - 18, 106 *et seq*, 182, 208 *et seq*

U

- Unleaded petrol - 200


V

- Valve clearances - 37, 185
- Vehicle identification numbers - 9

W


- Washer system - 136
- Water pump - 58, 199
- Weights - 6
- Wheel alignment - 152, 159
- Wheel cylinder - 117
- Wheels - 7, 18, 106 *et seq*, 152, 159, 182, 208 *et seq*
- Wheel (steering) - 148
- Windows - 136, 169
- Windscreen - 135, 168
- Wing - 162
- Wiper blade and arm - 134
- Wiper motor - 135
- Wiring diagrams - 218
- Working facilities - 11

EVERY MANUAL BASED ON
A STRIPDOWN AND
REBUILD



THE BOOK

DUCKHAMS





Models covered by this Manual

All FIAT Panda front-wheel-drive models including special and limited editions
903 cc ohv; 769 & 999 cc FIRE

Does not cover four-wheel-drive models

Haynes Manuals explain best

- Step-by-step procedures with hundreds of illustrations and photos
- Written from hands-on experience using common tools
- Colour spark plug diagnosis and bodywork repair
- Quick and easy fault diagnosis sections
- Wiring diagrams



H925909



ISBN 1 85010 516 2